


# 4 MATTRESS STAY ASSEMBLY



1. Bring frame down slowly to horizontal position.
2. Attach the mattress stay angles and mattress stay bar. (See fig. 3)
3. Place the mattress foundation onto the frame and return to the vertical position.
4. Attach the mattress foundation with (6) wood screws through the holes provided in the side rails of the bed frame. Place the nylon mattress strap between the foundation and the frame holes toward the foot of the bed. Run screw through frame hole, through strap and tighten into the foundation.




# 5 INSTALLING THE SPRINGS

1. Attach one spring in the outermost hole either side of the base angle. Using pliers, grip the top of the spring and stretch spring upwards and hook into the spring bar assembly. (see detail). Repeat for other side.
2. Bring frame slowly down to the horizontal position.
3. Place the mattress onto the foundation and secure with the mattress strap.
4. Return the frame to the vertical position and attach the balance of the springs starting from the outside holes working toward the middle.

NOTE: DEPENDING ON THE FRAME SIZE, NOT ALL HOLES IN THE FRAME MAY BE USED. SEE PARTS LIST FOR NUMBER OF SPRINGS FOR YOUR BED SIZE.




VERTICAL



HORIZONTAL

**THIS PAGE ONLY APPLIES IF YOU HAVE ORDERED A TILTING HEAD BOARD**



**Butt Hinge**  
(typical)

**Note:** King, Queen, Full have (3) & Twin have (2).

**Note:** Go to page (11) and step #4. These 2-holes in the tilting head board match up with the 2-holes on Mattress Stay Bar. We have sent (2) 1 1/2" x 1/4" bolts that are to replace the bolts from the Murphybed Kit. These new bolts will go through the Tilting Headboard & Mattress Stay Bar & Mattress Stay Angle. Use the 1/4" nuts from the Murphybed Kit to tighten. Tilting Headboard will come with the 5/16" holes partially drilled thru. You will need a 5/16" drill bit to finish drilling out the holes in the Tilting Headboard

